

Glazing Instructions for Project Out Windows

Installation Instructions

To install BR casement window:

1. Install sub frame, level and plumb. Fastening point are under windows stops(refer to drawings).
2. When sub frame in set(make sure fastening is good, Action suggest every 12"). Open casement and remove vertical leg not attached to the hinge(remove screws from horizontals to get leg out). Pull out vertical leg.
3. Install rubber block at bottom(1/2" rubber).
4. Slide in glass and rest on blocks.
5. Re-install vertical leg carefully. Put screws back in horizontals.
6. Close window and check for proper spacing from frame to window.
7. If needed shim so space is even.
8. Once set, shimmed and locked, wet seal front and back with black silicone.